

VACUUMJET SEAL

ES Sello Vacuumjet DE Vacuumjet Dichtschnur
IT Guarnizione Vacuumjet PT Vedante Vacuumjet FR Joint Vacuumjet



● Cad Insertion Point

JV

VACUUM




Patented



Ref.	A	B	C	mm
JV.030200	3	2.2	2.7	2.000
JV.050200	5	3.8	4.2	2.000


Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation



IMPORTANT !

Ensure joint is sealed using silicon.
Sellar con silicona la entrada de herramienta.
Dichtschnur an den Enden mit Silikon verkleben.
Sigillare con silicone l'entrata dell'utensile.
Vedar a linha de junta.
Coller ensemble les extrémités du joint.



TV


VACUUM




CONNECTION TUBE

ES Tubo Conexión DE Verbindungsrohr
IT Tubo connessione PT Tubo de Ligação FR Tube de connexion

● Cad Insertion Point



Ref.	A	B	E	L	R
TV.141650	10	16	8	50	1/4 GAS
TV.141675	10	16	8	75	1/4 GAS



IMPORTANT !